

Porsche 997 GT3 & GT3RS Full Maxflo Exhaust & Air Intake Installation Instructions

Congratulations on purchasing the finest Type 304 Stainless Steel Cat-Back emissions legal performance exhaust for your car. These systems were extensively tested on the street, chassis dyno and racetrack and offer the best combination of horsepower and torque gains with superlative Sports car sound. Fabspeed offers the following parts for the 997 GT3/GT3RS: equal length headers with 200cell sports cats, Rear Maxflo mufflers with dual 4" 102mm tips, muffler bypass pipes for the stock side mufflers and 4" 102mm replacement tips for the small 3" stock tip. Everything is an easy do it yourself installation.

997 GT3 GT3RS Headers

Parts List:

Left and Right side High performance headers with 200cell German catalytic converters that replace the stock 500 cell headers with flat collectors and a set of Copper Header Gaskets.

Install List:

1. Safely jack up car and always use jack stands.
2. Using a 22mm or 7/8" open end wrench to remove the primary and 2ndary oxygen sensors. Mark the 2ndary sensor. Then remove allen bolt that connects the clamp at the end of the headers to the stock 2ndary side mufflers. With a 13mm ratchet and 13mm socket with extension remove the headers and replace with the Fabspeed F1 Indy car quality headers. It is recommended that you replace the factory gaskets with Fabspeed leak proof copper gaskets.

997 GT3 GT3RS Maxflo Mufflers

Parts List:

Fabspeed Maxflo mufflers- 2 mufflers with 2 102mm 4" tips, 2 x 2.0" and 2 x 2.5" clamps and 2 T bolt Muffler band straps

Install List:

1. With a 13mm socket remove center muffler inlet pipes from sides of factory muffler. Remove band straps from muffler and remove stock muffler from car.
2. Reinstall Fabspeed dual high performance mufflers with band straps and inlet clamps that attach to stock side mufflers. Slowly adjust and tighten everything. Install dual 4" 102mm tips (available in mirror polished T304SS or satin black ceramic coated) and adjust length and tighten securely. Tighten everything.

997 GT3 GT3RS Maxflo SIDE Muffler Bypass Pipes

Parts List:

Fabspeed Maxflo muffler left and right bypass pipes that replace the 48lb 24Kg stock mufflers on all GT3 and GT3RS cars.

Install List:

1. Remove GT3 headers and then remove GT3/GT3RS side mufflers with a 13mm socket set.
2. Reinstall Fabspeed side muffler bypass pipes to the 997GT3 headers and connect to either the dual Fabspeed Maxflo high performance mufflers or to the stock GT3 center muffler. Slowly adjust and tighten everything.

997 GT3 GT3RS 102mm 4.0" Replacement Tip for Stock Porsche Center Muffler

Parts List:

Fabspeed Maxflo muffler left and right bypass pipes that replace the 48lb 24Kg stock mufflers on all GT3 and GT3RS cars.

Install List:

1. Remove stock GT3 tips with 13mm socket set.
2. Reinstall Fabspeed GT3 tip bracket onto muffler and tighten. Install tips and choose the length desired and tighten securely.

997 GT3 GT3RS Maxflo CUP Air Intake System

Fabspeed 997 GT3/GT3RS air intake fits all GT3 cars.

Install List:

1. Remove complete air box assembly from the car.
2. Remove the air box coverlid from back cover by loosening Philips screws.
3. Replace factory air filter at this time if you would like get a new high performance air filter.
4. Install aluminum CNC frame and tighten rear Philips screws to hold air filter in place.
5. The stainless steel rain drip edge is installed on the front of the aluminum air box frame and the 4 locking hex nuts and washers hold this piece in place.

If you have any questions, please contact Fabspeed tech support.

ENJOY YOUR NEW POWER AND SPORTSCAR SOUND. Let us know what you think and visit WWW.FABSPEED.COM for updates and new products for your car.

info@fabspeed.com 215-646-4945 (9828fax)