

## FERRARI 458 ITALIA

### Install notes:

#### Headers-

- It is recommended that the rear wheels and fender liners be removed to allow for easier access to the headers.
- Air line should be removed from both locations (Secondary air valve)(Header)before headers are removed. Air lines will be removed by removing (2) 5mm allen bolts per location.
- To access front portion of left side header. Unbolt air conditioner compressor and move aside. (**Note: Belt must be removed from compressor pulley. Make note of belt routing before removal of the belt!**)



- 3 bolts secure the air conditioner compressor to the engine block( **Do not remove lines from the compressor**)
- Secure compressor with mechanics wire. Do not let the compressor hang by the lines.
- Removal of all header bolts is now possible.

