

Ferrari F328 200 cell Sport Primary Catalytic Converter & Catbypass Pipe Installation Instructions

Notes F328 requires only 1 catalytic converter or only 1 catbypass pipe.

The Testarossa requires exactly 2 of these same catalytic converters and or 2 of the catbypass pipes.

1. Replace stock primary/main catalytic converter with either Fabspeed 200 cell sports race catalytic converters or Fabspeed catbypass pipes. You need a 22mm or 7/8 wrench to loosen and unscrew the oxygen sensors from the catalytic converters.
2. Reverse the process to install your Maxflo high performance catalytic converters. Use antiseize on all the bolts and nuts.
3. REVERSE the above procedures to put the 328 or Testarossa back together. You now have the most possible power and increased Ferrari F1 style sound that works with any rear muffler system.

