

## **Ferrari F348 200 cell Sport Primary Catalytic Converters, Catbypass Pipes Installation Instructions**

### **Ferrari F348 and Mondial—systems requires 2 parts**

1. Replace stock primary/main catalytic converters with either Fabspeed 200 cell sports race catalytic converters or Fabspeed catbypass pipes. You need a 22mm or 7/8 wrench to loosen and unscrew the oxygen sensors from the catalytic converters.
2. Reverse the process to install your Maxflo high performance catalytic converters. Use antiseize on all the bolts and nuts.
3. REVERSE the above procedures to put the 348 back together. You now have the most possible power for your 348 and increased Ferrari F1 style sound that works with any rear muffler.

