



Lamborghini Gallardo: Fabspeed Maxflo Catbypass/Sportcat Installation Instructions

1. Complete airbox assembly needs to be removed.
2. Remove the two 13mm hex nuts on dry sump oil tank and pull aside to facilitate removal of left catalyst.
3. Leave O2 sensors in cats...disconnect them and remove after cats have been pulled out.
4. When installing bypass pipes rotate the pipes until both front and rear flanges are lined up and seated. Then place the factory clamps in position and tighten sequentially to maintain alignment. (The factory clamps have a tighter "V" and seem to seal better.)
5. Anti-seize lubricant should be used on all sensors attached to Sportcat/catbypass pipes.