



MACAN 2.0L (2019+) COMPETITION AIR INTAKE
INSTALLATION GUIDE

Porsche Macan 2.0L (2019+) Competition Air Intake Installation Guide

1

Begin by removing the pictured mounting bolt. Set this aside as you will be re-using this



2



You will then need to detach the vacuum line from the stock intake tube as well as loosen the hose clamp using a slotted screwdriver. You will be provided new hose clamps.

3

Insert your new Fabspeed intake pipe through the hole in the head shield assembly as shown.



4



After lining up the bottom mounting bolts on the heat shield assembly with the factory silicone mount points, you will be able to drop in your new Fabspeed intake system.

5

Slide the silicone coupler over the existing factory intake hose and tighten both hose clamps. Attach the vacuum line as shown.



6



Insert and tighten the factory mounting bolt. Your install is now complete.