



INSTALL GUIDE

Porsche Homelink Connection for Fabspeed Valvetronic Exhausts

General guidelines for programming your Porsche's in-car garage door opener buttons (Homelink) to operate your Fabspeed exhaust valves.

1. For most vehicles, the ignition must be switched to the on position, the turn signals must be off, the engine must be off and the car doors must be shut.
2. Clear out anything previously programmed into the in-car system by holding down on the 2-outside buttons simultaneously for approximately 20 seconds, release the buttons once the in-car LED starts flashing rapidly. The system is ready for programming.



3. Decide which button on the overhead console that you want to teach to operate your exhaust valves to the **open** position. Press and hold the desired button until the indicator light flashes. You have 5 minutes to teach the button.



4. Stand in front of the vehicle with the Fabspeed key FOB approximately 12" away from the center of the radiator grille.
5. Press and hold the VALVES OPEN button on the Fabspeed key FOB (for more than 1 minute in some cases) until the vehicle's turn signals flash on and off **three times** or the indicator light on the overhead operating console starts flashing quickly. The turn signals flash three times and the indicator light flashes quickly to confirm that the new signal has been programmed successfully.
6. Several attempts with different distances between the vehicle and the original remote control may be necessary.
With some systems, the transmit button of the original remote control must be pressed again when the indicator light on the original remote control goes out.



7. Decide which button on your overhead console that you want to teach to operate your exhaust valves to the **closed** position. Press and hold the desired button until the indicator light flashes. You have 5 minutes to teach the button.
8. Stand in front of the vehicle with the Fabspeed key FOB approximately 12" away from the center of the radiator grille.
9. Press and hold the VALVES CLOSED button on the Fabspeed key FOB (for more than 1 minute in some cases) until the vehicle's turn signals flash on and off **three times** or the indicator light on the overhead operating console starts flashing quickly. The turn signals flash three times and the indicator light flashes quickly to confirm that the new signal has been programmed successfully.

CAUTION

- *Always allow car to cool before performing any installation(s) or service(s) on it.*
- *Always be sure to work on an even and level surface when raising vehicle(s) with a jack, and support all raised vehicles with locked jack stands once elevated.*
- *Fabspeed Motorsport recommends that all installations be supervised or verified by a trained professional technician.*
- *Fabspeed Motorsport is not responsible for any personal injury or damage(s) sustained to a vehicle during installation of aftermarket performance parts.*

If you have any questions, comments, or concerns related to your product, please contact us!